

A	
Air cleaner	6-23
Air conditioner & heater	3-35
Air conditioner filter	6-45
Axle oil	6-34
B	
Battery	6-42
Before starting engine	4-2
Belt tensioner	6-21
Boom kick out	4-22
Brake line filter	6-28
Bucket leveler	4-22
C	
Cab device	3-1
Camera	3-42
Charge air cooler	6-20
Cigar lighter	3-39
Cluster	3-2
Control device	3-32
Coolant level	6-17
E	
Engine control unit (ECU)	3-42
Engine oil filter	6-15
Engine oil level	6-15
F	
Fan belt	6-21
FNR remote control lever	3-33
Fuel filter	6-24
Fuel prefilter	6-24
Fuse box	3-41
G	
Gear selector lever	3-33
H	
Hydraulic oil changing	6-26
Hydraulic oil filling	6-26
Hydraulic oil level	6-26
L	
LCD	3-10
Loading and unloading	5-6
Lubrication	6-37
M	
Machine control unit (MCU)	3-41
Maintenance chart	6-13
Maintenance check list	6-10
Major components	2-1
Master switch	3-40
Monitor	3-11
P	
Pilot cut off switch	3-26
Pilot line filter	6-27
R	
Radiator and oil cooler	6-20
Recommended lubricants	6-9
Return filter	6-27
Radio and USB/MP3 player	3-43
S	
Safety hints	1-1
Safety labels	0-5
Seat	3-40
Specifications	2-2
Storage	4-25
Switches	3-25
T	
Tightening torque	6-5
Tire	6-29
Towing the machine	5-7
Transmission cold starting	4-6
Transmission control unit (TCU)	3-42
Transmission oil filter	6-32
Transmission oil level	6-32
Transportation	5-1
Travelling machine	4-10
Troubleshooting guide	7-1
W	
Warming up operation	4-8
Weight	2-7
Working method	4-15