

2. CHECK BEFORE STARTING THE ENGINE

1) Look around the machine and under the machine to check for loosen nut or bolts, collection of dirt, or leakage of oil, fuel or coolant and check the condition of the work equipment and hydraulic system. Check also loosen wiring, and collection of dust at places which reach high temperature.

※ **Refer to the daily check on the chapter 6, maintenance.**

2) After checking air pressure of tire, make sure that around the machine is clear.

3) Adjust seat to fit the contours of the operator's body for the pleasant operation.

4) Adjust the rear view mirror.

