

A		G	
Accel dial switch	3-24	Gauge	3-3
After engine start	4-4	H	
Air breather element	6-32	Handsfree	3-38
Air cleaner filter	6-25	Hydraulic breaker	8-1
Air conditioner & heater	3-30	Hydraulic oil changing	6-30
Air conditioner filter	6-43	Hydraulic oil filling	6-30
Alternate exit	0-12	Hydraulic oil level	6-30
Attachment lowering	4-23	L	
B		LCD	3-5
Battery	6-40	LCD display map	3-6
Before starting engine	4-2	LCD main operation display	3-3
Boom lowering	4-23	Levers & pedals	3-28
Bucket clearance adjustment	6-38	Lifting capacities	2-9
Bucket replacement	6-36	Lubricant specification	2-26
Bucket selection guide	2-18	M	
Bucket tooth replacement	6-37	Maintenance check list	6-11
C		Major component	2-1
Cab air filter	6-43	MCU (Machine Control Unit)	3-48
Cab device	3-1	Mode selection system	4-6
Changing machine control pattern	4-26	Monitor panel	3-2
Cigar lighter	3-37	Mounting and dismounting	1-12
Cluster	3-2	N	
Coolant	6-20	New machine operation	4-1
Cooling fan	6-24	O	
D		Oil cooler	6-23
Drain filter	6-32	Operating pattern	4-26
E		P	
Emergency engine starting connector	3-49	Pedals	3-28
Engine oil filter	6-18	Periodical replacement parts	6-5
Engine oil level	6-18	Pilot filter	6-32
Engine starting & stop	4-3	Pin & bushing lubrication	6-39
Engine starting by booster	6-41	Prefilter	6-26
Engine stop	4-5	Pilot lamps	3-7
F		Q	
Fan belt	6-24	Quick clamp	8-6
Fuel filter	6-27	R	
Fuel leakage	6-29	Radiator flushing	6-20
Fuel system bleeding	6-27	Radio & CD/MP3 player	3-42
Fuel tank	6-26		
Fuse & relay box	3-48		

RCV lever lubricate	6-35
Recommended oils	2-26, 6-10
Relieving pressure	6-3
Remote controller	3-40
Return filter	6-31
RCV lever operating pattern	4-26

S

Safety hints	1-1
Safety labels	0-5
Safety parts	6-5
Seat	3-47
Seat belt	3-47
Service meter	3-49
Service socket	3-39, 3-49
Specification for major component	2-22
Specification	2-2
Start switch	3-23
Storage	4-25
Suction strainer	6-31
Swing bearing grease	6-33
Swing gear & pinion grease	6-34
Swing reduction gear oil	6-33
Switch panel	3-23
Switches	3-9, 3-23

T

Torques-major component	6-8
Torques-fastener	6-6
Towing machine	4-15
Track adjustment	6-35
Track shoe selection	2-21
Transportation	5-1
Travel reduction gear oil	6-34
Traveling machine	4-13
Troubleshooting guide	7-1

U

Undercarriage	2-20
USB socket	3-38

W

Warming up operation	4-5
Warning lamps	3-4
Weight	2-7
Windshield	3-50
Working device operation	4-12
Working method	4-16
Working range	2-5