

Foreword	0-1	6. Efficient working method	4-11
Before servicing this machine	0-2	7. Operation in the special work sites	4-15
EC regulation approved	0-3	8. Normal operation of excavator	4-17
Table to enter S/No and distribution	0-4	9. Attachment lowering	4-18
Safety labels	0-5	10. Storage	4-19
Machine data plate	0-12	11. RCV lever operating pattern	4-21
Guide(Direction, S/No, Symbol)	0-13		
1. SAFETY HINTS		5. TRANSPORTATION	
1. Before operating the machine	1-1	1. Preparation for transportation	5-1
2. During operating the machine	1-6	2. Dimension and weight	5-2
3. During maintenance	1-13	3. Loading the machine	5-4
4. Parking	1-16	4. Fixing the machine	5-6
		5. Loading and unloading by crane	5-7
2. SPECIFICATIONS		6. MAINTENANCE	
1. Major components	2-1	1. Instruction	6-1
2. Specifications	2-2	2. Tightening torque	6-5
3. Working range	2-3	3. Fuel, coolant and lubricants	6-8
4. Weight	2-4	4. Maintenance check list	6-10
5. Lifting capacities	2-5	5. Maintenance chart	6-15
6. Bucket selection guide	2-7	6. Service instruction	6-17
7. Undercarriage	2-8	7. Electrical system	6-34
8. Specification for major components	2-9	8. Air conditioner and heater	6-37
9. Recommended oils	2-12		
3. CONTROL DEVICES		7. TROUBLESHOOTING GUIDE	
1. Cab devices	3-1	1. Engine	7-1
2. Cluster	3-3	2. Electrical system	7-2
3. Switches	3-7	3. Others	7-3
4. Levers and pedals	3-10	8. HYDRAULIC BREAKER	
5. Air conditioner and heater	3-13	1. Selecting hydraulic breaker	8-1
6. Others	3-15	2. Circuit configuration	8-2
4. OPERATION		3. Maintenance	8-3
1. Suggestion for new machine	4-1	4. Precaution when operating the breaker	8-4
2. Check before starting the engine	4-2	5. Quick clamp	8-6
3. Starting and stop the engine	4-3		
4. Operation of the working device	4-7		
5. Traveling of the machine	4-8		