


GROUP 4 DISASSEMBLY AND ASSEMBLY

1. CONTROL VALVE


1) DISASSEMBLY

(1) Illustration on the right shows the complete control unit.



73073CV001

(2) Mark the installation position of the different covers, the housing and cable harness with the valve housing.




73073CV002

(3) Loosen socket head screws.
Separate duct plate, 1st gasket, intermediate plate and 2nd gasket from the valve housing.

Special tool


Box spanner

5873 042 002



73073CV003

(4) Remove retaining clip.




73073CV004

- (5) Loosen socket head screws.
Separate cover from housing and cable harness.


Special tool
Box spanner

5873 042 002



73073CV005

- (6) Disassemble opposite cover.
Disconnect pressure regulator and remove cable harness.




73073CV006

- (7) Loosen socket head screws, remove fixing plate and pressure regulators(3EA).

Special tool
Box spanner

5873 042 002



73073CV007


- (8) Loosen two socket head screws and locate housing provisionally, using adjusting screws(Housing is under spring preload).

Now, loosen remaining socket head screws.

Special tool
Box spanner
Adjusting screws


5873 042 002

5870 204 036




73073CV008

- (9) Separate housing from valve housing by loosening the adjusting screws uniformly.
Special tool
Adjusting screws 5870 204 036




73073CV009

- (10) Remove components.



73073CV010

- (11) Remove opposite pressure regulators, housing as well as components accordingly.



73073CV011

2) ASSEMBLY

Check all components for damage and renew if necessary.


Prior to the installation, check free travel of all moving parts in the housing.

Spools can be exchanged individually.

Oil the components prior to the assembly.

Insert diaphragms with the concave side showing upward until contact is obtained.


Installation position, see arrows.



73073CV015

(1) Illustration on the right shows the following components.


- 1 Vibration damper
- 2 Follow-on slide
- 3 Pressure reducing valve



73073CV016

(2) Install components according to figure (1).

Preload compression spring of the follow-on slides and locate spool provisionally by means of cylindrical pins $\varnothing 5.0\text{mm}$ (Assembly aid), see arrows.




73073CV017

(3) Install two adjusting screws.


Assemble gasket (Arrow 1) and housing cover. Now, position the housing cover uniformly, using adjusting screws, until contact is obtained and remove cylindrical pins (Assembly aid) again (See the next figure).

Pay attention to the different housing covers. Install recess $\varnothing 15\text{mm}$ (Arrow 2), facing the spring of the pressure reducing valve.

Adjusting screws 5870 204 036



73073CV018




73073CV019

(4) Fasten housing cover by means of socket head screws.

· Torque limit : 0.56kgf · m(4.06lbf · ft)

Special tool

Box spanner 5873 042 002



73073CV020

(5) Introduce pressure regulators and fix by means of fixing plates and socket head screws.


Install fixing plate, with the claw showing downward.

Pay attention to the radial installation position of the pressure regulators, see figure.

· Torque limit : 0.56kgf · m(4.06lbf · ft)

Special tool

Box spanner 5873 042 002




73073CV021

Pre assemble opposite side

(6) Illustration on the right shows the following components.

- 1 Main pressure valve
- 2 Follow on slide
- 3 Vibration damper



73073CV022


(7) Install components according to figure (6).
 Preload compression springs of the follow-on slides and locate spool provisionally by means of cylindrical pins $\varnothing 5.0\text{mm}$ (Assembly aid), see arrows.
 Install two adjusting screws.
 Assemble gasket (Arrow 1) and housing cover, and position them uniformly against shoulder, using adjusting screws.
 Pay attention to the different housing covers—install the recess $\varnothing 19\text{mm}$ (Arrow 2), facing the main pressure valve.
 Now, fasten housing cover by means of socket head screws.

· Torque limit : $0.56\text{kgf} \cdot \text{m}$ ($4.06\text{lbf} \cdot \text{ft}$)
 Remove cylindrical pins (Assembly aid) again.

Special tool

Adjusting screws 5870 204 036

Box spanner 5873 042 002



73073CV023

(8) Introduce pressure regulators and fix by means of fixing plates and socket head screws.
 Install fixing plates, with the claw showing downward.

Pay attention to the radial installation position of the pressure regulators, see figure.

Special tool


· Torque limit : $0.56\text{kgf} \cdot \text{m}$ ($4.06\text{lbf} \cdot \text{ft}$)

Box spanner 5873 042 002



73073CV024

(9) Introduce cable harness and connect pressure regulators (6EA).
 Pay attention to the installation position of the cable harness, see also markings (See figure(2), page 3-75).



73073CV025


(10) Introduce female connector against shoulder, with the groove facing the guide nose of the cover.

Install gasket (Arrow) and fasten cover by means of socket head screws.

· Torque limit : 0.56kgf · m(4.06lbf · ft)

Special tool


Box spanner 5873 042 002



73073CV026

(11) Fix female connector by means of retaining clamp, see figure.

Install opposite cover.




73073CV027

(12) Install two adjusting screws and mount gasket .

Pay attention to the different gaskets, see on the right figure and (15).

Special tool

Adjusting screws 5870 204 063




73073CV028

Intermediate plate-Version with screens


(13) Insert screws(6EA) flush mounted into the bore of the intermediate plate, see arrow.

Pay attention to the installation position-screws are showing upward(Facing the duct plate).




73073CV029

(14) Mount intermediate plate, with the screens showing upward.



73073CV030

(15) Mount gasket




73073CV031

(16) Mount duct plate and fasten it uniformly by means of socket head screws.

· Torque limit : 0.97kgf · m(7.0lbf · ft)

Special tool

Box spanner 5873 042 002




73073CV032

(17) Equip screw plug(8EA) with new O-rings and install them.

· Torque limit : 0.61kgf · m(4.43lbf · ft)

The installation of the hydraulic control unit is described, starting from page 3-136.




73073CV033

2. TRANSMISSION

1) DISASSEMBLY

(1) Remove filter unit

Demount warning switch(Arrow) from filter head.




73073TM002

Separate oil filter from filter head.

Special tool


Belt spanner

5870 105 005



73073TM003

Loosen hexagon head screws and separate filter head from duct plate.



73073TM004


(2) Separate hydraulic control unit and duct plate from gearbox housing

Loosen socket head screws, install two adjusting screws and separate control unit from duct plate.

Special tool

Adjusting screw

5870 204 031




73073TM004

Remove both gaskets as well as intermediate plate.

Special tool

Adjusting screws 5870 204 031




75773TM051

Loosen socket head screws and hexagon nuts and separate duct plate from gearbox housing.

Now, remove flat gasket.

Special tool


Adjusting screws 5870 204 031



75773TM052

(3) Remove and disassemble converter safety valve

Pull converter safety valve out of the housing bore.




75773TM053

Illustration on the right shows the required special tool for the disassembling of the converter safety valve.

1 Converter safety valve


Special tool

Assembly aid 5870 345 084




73073TM009

Preload compression spring carefully, remove cylindrical pin(See on the right figure) and demount components(See on the below figure).



73073TM010




73073TM011

(4) Engine connection-Converter

Remove lock plate and loosen hexagon head screws.


Remove disk and pry input flange from the shaft.



73073TM015

Loosen screw connection.

Mark radial installation position of the housing cover.




73073TM016

Separate cover along with converter from the transmission, using lifting device.


Special tool

Set of eye bolts 5870 204 002



75773TM057

Press input shaft, respectively converter out of the cover (Ball bearing).



75773TM058

Squeeze circlip out and remove ball bearing.


Special tool

Set of internal pliers 5870 900 013




75773TM059

Loosen hexagon head screws and separate membrane from converter.



75773TM060

Loosen hexagon head screws and separate input shaft from the membrane.




75773TM061

Remove inductive transmitter(n Enging).



75773TM062


Loosen hexagon head screws and remove converter housing.



75773TM063

(5) Remove transmission pump

Loosen socket head screws.




75773TM064

Apply separating device on the splines runout of the stator shaft and pull pump out of the housing bores, using two-leg puller.

Special tool


Separating device 5870 300 024

Two-leg puller 5870 970 004




75773TM065

Separate transmission pump from stator.
Separate cam plate from pump.
If traces of wear should be encountered in the pump housing or the cam disk, the complete pump has to be renewed.
Now, fit cam disk again and fix it by means of grooved pins(2EA).



75773TM066


Loosen hexagon head screws and remove oil feed housing.
Now, remove flat gasket.



75773TM067

(6) Converter pressure valve

Pull converter pressure valve out of the housing bore.




73073TM028

Illustration on the right shows the special tool required for the disassembling of the converter pressure valve.

1 Converter pressure valve

Special tool

Assembly aid 5870 345 084



73073TM029

Preload compression spring carefully, drive roll pin out and remove components.


Special tool

Assembly aid 5870 345 084



73073TM030

Loosen hexagon head screws, demount cover and remove flat gasket.



73073TM031

(7) Demount output, input and clutches


Remove lock plate, loosen hexagon head screws, and pry the converter-side output flange from the shaft.

Now, pry shaft seal out of the housing bore.

Tilt gearbox 180° and remove rear output flange accordingly.


Special tool

Pry bar 5870 345 065




73073TM035

Demount speed sensor as well as both inductive transmitters(Arrows).




73073TM036

Loosen hexagon nuts and remove the two covers(Arrows).
Loosen screw connection.




73073TM037

Drive both cylindrical pins(Arrows) out.



73073TM038


Separate housing cover carefully from gearbox housing, using lifting device.
Special tool
Lifting chain 5870 281 047



73073TM039

On the right figure shows the installation position of the single clutches as well as of the input and output.

- KV Forward clutch
- KR Reverse clutch
- K1 1st speed clutch
- K2 2nd speed clutch
- K3 3rd speed clutch
- K4 4th speed clutch
- AN Input
- AB Output



73073TM040

The following figures describe the common removal of all clutches.


For this purpose, the housing cover, combined with special tool is necessary.

The removal of single clutches without help of the housing cover and the handles is extremely difficult because of the installation condition.

Besides, there is the danger of injuries.

Prior to the common removal of the clutches, the output shaft must be removed, see the below figure.

Loosen socket head screws and remove output shaft as well as both oil baffle plates.



73073TM042

Assemble housing cover carefully until contact is obtained.

Fix all clutches in the housing cover, using handles.

Special tool

Handle(6EA needed) 5870 260 010




73073TM201

Separate housing cover along with clutches from gearbox housing, using lifting device.


Special tool

Handle(6EA needed) 5870 260 010



73073TM200

Fasten housing cover on assembly car.




73073TM045

Tilt housing cover 180°.

Remove handles.


Special tool

Handle(6EA needed) 5870 260 010



73073TM046

Remove K2 clutch.




73073TM047

Remove K1 clutch, at the same time, lift K4 clutch.



73073TM048

Lift K3 clutch out of the housing cover.




73073TM049

Remove K4 clutch, at the same time lift input slightly.



73073TM050


Separate KV and KR clutches together with input from the housing cover.



Remove bearing outer race and pull output shaft(Power take-off) out of the housing bore.



Squeeze rectangular ring(Arrow) out and separate ball bearing from shaft.




If contrary to the recommendation, the tapered roller bearings of the clutches as well as of the input and output would not be renewed, the allocation of the inner and outer races to the single assemblies must at least be maintained.
Mark bearing inner and outer races accordingly.

(8) Disassemble KV and KR clutch

The following figures show the disassembly of the KV clutch.

The disassembly of the KR clutch is analogous.

Squeeze rectangular ring(Arrow) out.



73073TM54

Pull tapered roller bearing from the shaft.
Demount opposite tapered roller bearing accordingly.

Special tool

Grab sleeve

5873 001 057

Basic set

5873 001 000



73073TM55

Separate plate carrier from shaft.

Special tool


Hammer

5870 280 004



73073TM56

Squeeze snap ring out and remove plate pack.



73073TM57

Preload compression spring, squeeze circlip out and remove components.

Special tool


Assembly aid 5870 345 086

Set of external pliers 5870 900 015




73073TM58

Lift piston by means of compressed air out of the cylinder bore and remove it.



73073TM59

Remove both O-rings.



73073TM60

Squeeze inner circlip(Shaft) out.

Special tool

Set of external pliers 5870 900 015




73073TM61


Locate idler gear by means of separating device(See on the right figure) and press it from the shaft(See on the below figure).
Remove released needle bearing.

Special tool

Separating device 5870 300 028



73073TM62



73073TM63

Squeeze circlip out and remove ball bearing.

The disassembly of the KR clutch has to be carried out accordingly.

Special tool

Set of internal pliers 5870 900 013




73073TM64

(9) Disassemble K1, K2 and K3 clutch

The following Figures show the disassembly of the K3 clutch.

The disassembly of the K1 and K2 clutches is analogous.

Squeeze rectangular ring(Arrow) out.



73073TM65

Pull tapered roller bearing from the shaft.
Remove opposite tapered roller bearing accordingly, see Figure , .


Special tool

Grab sleeve 5873 001 057

Grab sleeve 5873 001 058

(K3 on output side)

Basic set 5873 001 000



73073TM66

Remove running disk, axial needle cage and axial washer.




73073TM67

Remove idler gear.



73073TM68

Remove both needle bearings as well as axial bearing.



73073TM69

Squeeze snap ring out and remove plate pack.



73073TM70

Preload compression spring, squeeze circlip out and remove components.

Special tool

Assembly aid(K2 and K3) 5870 345 085


Assembly aid(K1) 5870 345 086

Set of external pliers 5870 900 015



73073TM71

Press piston out of the plate carrier, using compressed air.



73073TM72

Pry plate carrier from the shaft.

Special tool

Pry bar 5870 345 065



73073TM73

(10) Disassemble K4 clutch

Squeeze rectangular ring out and pull tapered roller bearing from the shaft.

Remove opposite tapered roller bearing accordingly.

Special tool

Grab sleeve 5873 001 057

Basic set 5873 001 000



73073TM74

Squeeze circlip out and separate plate carrier from the shaft.

Special tool


Assembly aid 5870 345 085

Set of external pliers 5870 900 015



73073TM75

Squeeze snap ring out and demount plate pack.



73073TM76

Preload compression spring, squeeze circlip out and remove components.

Demount piston.

The separation of shaft and gear is not possible(Shrink fit).

Special tool

Assembly aid 5870 345 085




73073TM77

(11) Disassemble input shaft

If necessary, press turbine shaft out of the input shaft.

The turbine shaft is axially fixed by means of a snap ring which will be destroyed at the pressing out.



73073TM78

Squeeze rectangular ring out and pull off the tapered roller bearing.


Pull off the opposite tapered roller bearing.

The separation of input shaft 1 and gear 2 is not possible (Shrink fit).

Special tool

Grab sleeve 5873 001 058

Basic set 5873 001 000



73073TM79

2) ASSEMBLY


If contrary to the recommendation, the tapered roller bearings of the clutches as well as of the input and output would not be renewed, the allocation of the inner and outer races to the single assemblies must at least be maintained.

(1) Mount oil pipes

To ensure the correct assembly of the oil pipes, the use of the specified special tool is imperative.

Install studs (Arrows).

- Torque limit : 0.92kgf · m (6.64lbf · ft)
- Insert studs with Loctite.



73073TM090

Place distance tubes over the studs.




73073TM091

Insert suction tube 1, pressure pipe 2 and pressure pipe lubrication 3 into the housing bores.

Fasten suction tube 1 and pressure pipes 2 provisionally by means of socket head screw and hexagon nuts.

- Torque limit : 2.35kgf · m (17.0lbf · ft)




73073TM092

Locate both pressure pipes by means of special device.

Special tool

Tension bar 5870 654 030



73073TM093

Tilt housing 180°.

Roll in suction tubes as well as pressure pipes (Arrows) into the housing bores, using special tool.

Pipe end of pressure pipes (Arrows) must be slightly below the housing plane face, if necessary equalize.


Special tool

Rolling tool 5870 600 003

Rolling tool 5870 600 004

Rolling tool 5870 600 005

Rolling tool 5870 600 006



73073TM094

Tilt housing 180°.


Check installation position of the two pressure pipes and correct if necessary.

Pipes must be located in the special device without play and pressure.

Now, remove special device.

Special tool

Tension bar 5870 654 030



73073TM095

Equip screw plug with new O-ring and install it.

• Torque limit : 5.2kgf · m(37.6lbf · ft)




73073TM096

Insert all bearing outer races into the housing bore.

In the case that already run bearings are reused, pay attention to the allocation of the bearing outer races, see also Note, page 3-101.

Pay attention to the corresponding markings.




73073TM097

Insert both oil pipes(Arrows) into the housing cover, tilt housing cover 180, and roll in oil pipes into the housing bores.

The pipe end must be situated slightly below the housing plane face.

Special tool


Rolling tool 5870 600 005



73073TM098


Install studs (M8 x 25, 27EA) according to the figure on the right.

- Torque limit : 0.92kgf · m(6.64lbf · ft)



73073TM099

Insert set screws(2EA) into the housing bores(Arrows).



73073TM099A

Assemble KV and KR clutch


The following figures describe the assembly of the KV clutch.

Pre-assemble plate carrier(Figure ~)

Check function of the drain valve.


Ball may not seize, if necessary clean by means of compressed air.

Insert both O-rings(Arrows) scroll free into the recesses of the piston and oil them.



73073TM100

Assemble piston until contact is obtained.
Pay attention to the installation position, see on the right figure.



73073TM101

Introduce compression spring along with spring cup(2EA).



73073TM102

Preload compression spring and fix it by means of circlip.

Special tool

Assembly aid

5870 345 086



73073TM103

KV, KR plate pack


The plate equipment, respectively stacking of KV and KR clutch is identical. The following draft shows the installation position of the components.

- 1 Plate carrier
- 2 Piston
- 3 Outer plate-one-sided coated
- 4 Inner plates
- 5 Outer plates-coated on both sides
- 6 Snap ring(Optional s = 2.1~4.2mm)
- 7 End shim

Install outer plate 3 with the uncoated side facing the piston, respectively the end shim.

Install on the end shim side **two** outer and inner plates each.


- Effective number of friction surfaces =18.




Adjust plate clearance = $2.5^{+0.2}$ mm.

For the adjustment of the plate clearance there are snap rings of different thickness available.

To ensure a faultless measuring result, install plates for the moment without oil. Introduce plate pack according to the upper draft.



Mount end shim and squeeze snap ring(e.g. s = 3.0mm) in.




73073TM106

Press end shim on with about 10kg and measure Dimension from the end face/plate carrier to the end shim.

Dimension e.g. 7.25mm

Special tool

Digital-Depth gauge 5870 200 072




73073TM107

Press end shim against snap ring (Upward) until contact is obtained and determine Dimension .

Dimension e.g. 4.75mm

Special tool

Digital-Depth gauge 5870 200 072



73073TM108

EXAMPLE

Dimension 7.25mm

Dimension - 4.75mm

Difference = Plate clearance = 2.50mm

In case of deviations from the required plate clearance, correct by means of corresponding snap ring(s = 2.1~4.2mm).
Now, remove plate pack, oil and install it again.

Introduce idler gear until all inner plates are accommodated.
This step makes the later assembling of the idler gear easier.
Now, remove idler gear again.



73073TM109

Install stud(Arrow).
Use Loctite.
· Torque limit : 1.73kgf · m(12.5lb · ft)



73073TM110

) Insert ball bearing until contact is obtained and fix it by means of circlip.



73073TM111

) Assemble needle bearing.



73073TM112

-) Press idler gear against shoulder.
Support it on the bearing inner race.




73073TM113

-) Fix idler gear axially by means of circlip.
At KR clutch there is no recess in the shaft-assembly circlip until contact on the bearing inner race is obtained.

Special tool

Set of internal pliers 5870 900 013




73073TM114

-) Assemble pre-assembled plate carrier until contact is obtained.
Only if the plate carrier plane face is overlapping with the shaft collar, the accommodation of all inner plates is ensured, see on the below figure.




73073TM115



73073TM116

-) Press tapered roller bearing against shoulder.
Install opposite tapered roller bearing.



73073TM117

-) Check function of clutch by means of compressed air.
At correctly installed components, the closing, respectively opening of the clutch is clearly audible.



73073TM118

(2) Assemble K1, K2 and K3 clutch

The following figures describe the assemble of the K3 clutch.

The assembly of the K1 and K2 clutches has to be carried out accordingly.

Install stud(Arrow).

Use Loctite.

- Torque limit : 1.73kgf · m(12.5lbf · ft)




73073TM125

Assemble plate carrier until contact is obtained.




73073TM126

Check function of the drain valve.
Ball may not seize, if necessary clean by means of compressed air.
Insert both O-rings(Arrows) scroll free into the piston recesses and oil them.




73073TM127

Introduce piston until contact is obtained.
Pay attention to the installation position, see on the right figure.



73073TM128

Introduce compression spring along with spring cup(2EA).



73073TM129

Preload compression spring and fix it by means of circlip.

Special tool

Assembly aid(K2 and K3) 5870 345 085

Assembly aid(K1) 5870 345 086



73073TM130

K1, K2 and K3 plate pack


The K1, K2 and K3 plate stacking of clutches are identical.

The following draft shows the installation position of the components.

- 1 Plate carrier
- 2 Piston
- 3 Outer plate-one-sided coated
- 4 Inner plates
- 5 Outer plates-coated on both sides
- 6 Snap ring(Optional $s = 2.1 \sim 4.2\text{mm}$)
- 7 End shim

Install outer plate 3 with the uncoated side facing the piston.

· Effective number of the friction surfaces = 16.




73033TM15

Adjust plate clearance = $2.1^{+0.2}$ mm :

For the plate clearance adjustment there are snap rings of different thickness available.

To ensure a faultless measuring result, install the plates for the moment without oil.

Introduce plate pack according to the upper draft.



73073TM135

Fit end shim and squeeze snap ring(e.g. 3.0mm) in.




73073TM136

Press end shim on with about 10kg, and measure Dimension from the end face/plate carrier to the end shim.

Dimension e.g. 8.20mm

Special tool

Digital-Depth gauge 5870 200 072




73073TM137

Press end shim against snap ring(Upward) until contact is obtained, and determine Dimension .

Dimension e.g. 6.00mm

Special tool

Digital-Depth gauge 5870 200 072



73073TM138

EXAMPLE :

Dimension e.g. 8.20mm

Dimension e.g. - 6.00mm


Difference = Plate clearance = 2.20mm

In case of deviations from the required plate clearance, correct by means of corresponding snap ring(S =2.1~4.2mm).

Now, demount plate pack, oil and install it again.

Assemble running disk 1(50 × 70 × 4), axial needle cage 2 and axial washer 3 (50 × 70 × 1).

Install running disk 1 with the chamfer facing the axial needle cage.



73073TM139

Assemble both needle bearings.



73073TM140

Introduce idler gear until all inner plates are accommodated.




73073TM141

Assemble axial washer 3(50 × 70 × 1), axial needle cage 2 and running disk 1 (50 × 70 × 4).

Install running disk 1 with the chamfer facing the axial needle cage.

Only if the running disk is overlapping with the shaft collar, the accommodation of all inner plates is ensured.



73073TM142

Press tapered roller bearing against shoulder.




73073TM143

Press tapered roller bearing against shoulder.



73073TM144

Check function of the clutch by means of compressed air.
At correctly installed components, the closing, respectively opening of the clutch is clearly audible.



73073TM145

(3) Assemble K4 clutch

Undercool shaft (About -80°C), heat gear (About $+120^{\circ}\text{C}$) and assemble it until contact is obtained.



73073TM150

Locate gear axially by means of circlip.
Special tool
Set of external pliers 5870 900 015



73073TM151

Install stud(Arrow).

Use Loctite.

- Torque limit : 1.73kgf · m(12.5lbf · ft)




73073TM152

Check function of the drain valve.

Ball may not seize, if necessary clean by means of compressed air.


Insert both O-rings(Arrows) scroll free into the piston recesses and oil them.



73073TM153

Introduce piston until contact is obtained.

Pay attention to the installation position, see on the right figure.



73073TM154

Install compression spring and spring cup(2EA), preload and fix by means of circlip.

Special tool

Assembly aid

5870 345 085



73073TM155


K4 plate pack

The following draft shows the installation position of the components.

- 1 Plate carrier
- 2 Piston
- 3 Outer plate-one-sided coated
- 4 Inner plates
- 5 Outer plates-coated on both sides
- 6 Snap ring(Optional $s = 2.1\sim 4.2\text{mm}$)
- 7 End shim

Install outer plate 3 with the uncoated side facing the piston.

- Effective number of friction surfaces = 10.




73033TM16

Adjust plate clearance = $1.2^{+0.2}\text{mm}$:

For the plate clearance adjustment there are snap rings of different thickness available.


To ensure a faultless measuring result, install the plates for the moment without oil.

Introduce plate pack according to the draft(See the preceding page).



73073TM160

Fit end shim and squeeze circlip(e.g. $s = 3.0\text{mm}$) in.



73073TM161

Press end shim on with about 10kg and measure Dimension from the end face/plate carrier to the end shim.

Dimension e.g. 7.20mm

Special tool

Digital-Depth gauge 5870 200 072




73073TM162

Press end shim against snap ring (Upward) until contact is obtained and determine Dimension .

Dimension e.g. 6.00mm

Special tool

Digital-Depth gauge 5870 200 072



73073TM163

EXAMPLE

Dimension e.g. 7.20mm

Dimension e.g. - 6.00mm

Difference = Plate clearance = 1.20mm

In case of deviations from the required plate clearance, correct by means of corresponding snap ring(S = 2.1~4.2mm).

Introduce idler gear until all inner plates are accommodated.


This step makes the later assembling of the idler gear easier.

Now, remove idler gear again.




73073TM164

Assemble both axial washers as well as needle cage.
Upper and lower axial washer have the same thickness(50 × 70 × 1).




73073TM165

Assemble both needle bearings.




73073TM166

Assemble idler gear.




73073TM167

Assemble axial washer 3(50 × 70 × 1)
needle cage 2 and running disk 1(50 × 70 × 4).
Install running disk 1 with the chamfer facing the needle cage.



73073TM168

Assemble pre-assembled plate carrier until all inner plates are accommodated.



73073TM169

Fix plate carrier axially by means of circlip.

Special tool

Set of external pliers 5870 900 015

Handle 5870 260 010



73073TM170

Press tapered roller bearing against shoulder.


Install opposite tapered roller bearing.



73073TM171

Check function of the clutch by means of compressed air.

At correctly installed components, the closing, respectively opening of the clutch is clearly audible.



73073TM173


(4) Pre-assemble input shaft

Undercool the input shaft(About -80°C),
heat gear(About $+120^{\circ}\text{C}$) and assemble it
until contact is obtained.




73073TM174

Fix gear axially by means of circlip.



73073TM175

Squeeze snap ring into the recess of the
turbine shaft.



73073TM176

Introduce turbine shaft until the snap ring
snaps into the recess of the input shaft-
turbine shaft is axially fixed.




73073TM177

Press both bearing inner races against shoulder.



73073TM178

Install ball bearing.
Squeeze rectangular ring (Arrow) in and hook it in.



73073TM179

Insert output shaft into the housing bore until contact is obtained.



73073TM180

(5) Install pre-assembled output shaft and clutches

The following figures describe the **common** installation of all clutches.


For it, the housing cover, combined with special tool is needed.

The assembly of single clutches without housing cover and handles is extremely difficult because of the installation conditions.


⚠ Besides, there is the danger of injury.

Insert all bearing outer races into the housing cover until contact is obtained.


In the case that already run bearings are reused, pay attention to the allocation of the bearing outer races, see also Note, page 3-102.




Insert KR clutch, input shaft and KV clutch together into the housing cover.



Install K4 clutch.




Install K3 clutch.




73073TM193

Position K1 clutch.




73073TM194

Insert K2 clutch.




73073TM195

Figure on the right shows the installation position of the single clutches in the housing cover.




73073TM196

Locate all clutches by means of handles.
 Special tool
 Handle(6EA needed) 5870 260 010




73073TM197

Squeeze rectangular rings(7 pieces, see Arrows) in and hook them in.
 Now, grease rectangular rings and align them centrally.




73073TM198

Tilt housing cover 180°. .
 Mount eye bolts, see Arrows.
 Special tool
 Eye bolt M20(2EA) 0636 804 003
 Eye bolt M16(1EA) 0636 804 001
 Puller device 5870 000 017



73073TM199

Install adjusting screws.
 Position housing cover by means of lifting device carefully on the gearbox housing until contact is obtained, respectively position the clutches in the gearbox housing.
 Pay attention to the overlapping of the oil pipes with the bores in the housing cover.
 Special tool
 Lifting chain 5870 281 047
 Adjusting screws 5870 204 007




73073TM200

Remove handles again.

Special tool

Lifting chain

5870 281 047




73073TM201

Separate housing cover from gearbox housing, using lifting device.

Special tool

Lifting chain


5870 281 047



73073TM202


(6) Output

Assemble sheet and press both bearing inner races against shoulder until contact is obtained.




73073TM203

Insert bearing outer race (Arrow) into the housing bore until contact is obtained.




73073TM204

Position screening plate.



73073TM205

Insert output shaft.



73073TM206

Fasten both sheets by means of socket head screws(4EA).
Insert socket head screws with Loctite.
· Torque limit : 2.35kgf · m(17.0lbf · ft)




73073TM207

Squeeze rectangular rings(6EA) into the recesses of the clutch shafts and hook them in.
Now, grease rectangular rings and align them centrally.



73073TM208

Insert both O-rings(Arrows) into the annular groove of the oil pipes and grease them.



73073TM209

Cover mounting face with sealing compound Loctite.

Install adjusting screws(S) and position housing cover carefully against gearbox housing until contact is obtained, using lifting device.

Pay attention to the overlapping of the oil pipe with the bores in the housing cover.

Special tool


Adjusting screws 5870 204 007

Lifting chain 5870 281 047



73073TM210

Install both cylindrical pins.




73073TM211

Fasten housing cover by means of hexagon head screws.

· Torque limit : 4.69kgf · m(33.9lbf · ft)

Pay attention to the position of the fixing plate, see Arrow.



73073TM212

Install shaft seal, with the sealing lip facing the oil chamber.

By application of the prescribed driver, the exact installation position is obtained.

Wet rubber-coated outer diameter with spirit.

Grease sealing lip.

Special tool

Driver 5870 048 057




73073TM213

Heat the output flange(Maximum 90°C), assemble it and fix it by means of washer and hexagon head screws.

Wet contact area of washer with sealing compound Loctite.

· Torque limit : 3.47kgf · m(25.1lb · ft)



73073TM214


Fix hexagon head screws by means of lock plate.

Install output flange on the converter side accordingly(Figure ~).

Special tool

Driver 5870 057 011

Handle 5870 260 002




73073TM215

(7) Converter pressure valve

The illustration on the right shows the components of the converter pressure valve.

- 1 Piston
- 2 Compression spring
- 3 Valve insert
- 4 Roll pin




73073TM220

Introduce compression spring and piston, preload and fix them by means of roll pin.

Special tool


Assembly aid

5870 345 084



73073TM221

Insert pre-assembled converter pressure valve into the housing bore.



73073TM222


(8) Oil feed housing-Transmission pump

Install two adjusting screws (Arrows) and mount flat gasket.

Special tool

Adjusting screws


5870 204 011



73073TM223

Mount oil feed housing and fix it provisionally by means of washers and hexagon head screws.

Screw the hexagon head screws in only until contact is obtained-**do not tighten**.




73073TM224

Install two adjusting screws and introduce stator shaft until contact is obtained.
Pay attention to the overlapping of the bores.


Special tool

Adjusting screws 5870 204 007




73073TM25

Install O-ring(Arrow) and oil it.




73073TM26

Introduce transmission pump until contact is obtained.
Pay attention to the overlapping of the bores.



73073TM27


Equip socket head screws with new O-rings(Arrow).
Grease O-rings.



73073TM28

Fasten transmission pump by means of socket head screws.

- Torque limit : 4.69kgf · m(33.9lbf · ft)




73073TM229


Fix oil feed housing finally by means of hexagon head screws(Mount flat washers).

- Torque limit : 2.55kgf · m(18.4lbf · ft)

Pay attention to the installation position of the fixing plate(Arrow), see the next figure.




73073TM230



73073TM231

Fit flat gasket and fasten cover by means of hexagon head screws.

- Torque limit : 2.35kgf · m(17.0lbf · ft)




73073TM232

(9) Engine connection-Converter

Fasten converter housing by means of hexagon head screws.


- Torque limit : 6.93kgf · m(50.2lbf · ft)



73073TM233

Fasten input shaft, membrane and disk by means of hexagon head screws.


- Torque limit : 11.7kgf · m(84.8lbf · ft)



73073TM234

Fasten membrane on the converter, using hexagon head screws(Mount flat washers).

- Torque limit : 11.7kgf · m(84.8lbf · ft)
- Insert hexagon head screws with Loctite.



73073TM235


Introduce converter until contact is obtained.

Impulse disk of the converter must be centrally to the bore of the inductive transmitter, see on the below figure.

Only in this way it is ensured that the converter has been completely introduced.



73073TM236



73073TM237

Insert ball bearing until contact is obtained and fix it by means of circlip.

Special tool

Set of internal pliers 5870 900 013



73073TM238

Assemble housing cover.

Install input flange, fit disk and pull cover by means of hexagon head screws evenly against shoulder.


Pay attention to the radial installation position of the cover.



73073TM239

Fasten cover by means of hexagon head screws and nuts on the converter housing.

• Torque limit : 4.69kgf · m(33.9lbf · ft)



73073TM240

Fasten input flange finally and fix hexagon head screws by means of lock plate.

• Torque limit : 3.47kgf · m(25.1lbf · ft)

Special tool

Driver 5870 057 010

Handle 5870 260 002




73073TM241

(10) Converter safety valve

The illustration on the right shows the components of the converter safety valve.

- 1 Plate
- 2 Ball
- 3 Compression spring
- 4 Valve insert
- 5 Valve sleeve
- 6 Cylindrical pin




73073TM245

Assemble components according to figure , preload and fix by means of cylindrical pin.


Special tool

Assembly aid 5870 345 084



73073TM246


Insert converter safety valve into the housing bore until contact is obtained.



73073TM247

(11) Fit duct plate


Install both screw plugs(Arrows),
Install new sealing rings.



73073TM248

Install gasket, place duct plate against shoulder and fasten it by means of socket head screws and hexagon nuts(Mount flat washers).

- Torque limit : 2.55kgf · m(18.4lbf · ft)



73073TM249

(12) Fit hydraulic control unit


Install two adjusting screws.

Mount gasket 1, intermediate plate 2 and gasket 3.


Pay attention to the installation position of the different gaskets, see also the following draft.

Special tool

Adjusting screws 5870 204 031




73073TM250



3-135(4) (740-7)

Fasten complete control unit on the duct plate, using socket head screws.

- Torque limit : 0.97kgf · m(7.01lb · ft)




73073TM251

(13) Filter

The illustration on the right shows the components of the filter unit.


Install new O-rings(Arrows)



73073TM252


Fasten intermediate plate and filter head by means of hexagon head screws (Mount flat washers).

- Torque limit : 2.55kgf · m(18.4lb · ft)




73073TM253

Oil gasket and tighten exchange filter hand-tight.




73073TM254

If necessary, install warning switch
(According to the version).



73073TM255


Insert O-ring(Arrow) into the annular groove of the oil feed covers.



73073TM256

Fasten the two covers(Arrows) by means of hexagon nuts(Mount flat washers) on the housing.


- Torque limit : 2.55kgf · m(18.4lbf · ft)



73073TM257

Mount oil level tube.
Install screw plug(Arrow).
Install new gaskets.

- Torque limit : 2.35kgf · m(17.0lbf · ft)
- Torque limit(Screw plug M26 × 1.5) :
8.16kgf · m(59.0lbf · ft)




73073TM258

(14) Speed sensor and inductive transmitter

Grease O-ring, introduce speed sensor(Arrow) and fasten it by means of socket head screw.

- Torque limit : 2.35kgf · m(17.0lbf · ft)

34 Speed-output and -speedometer



73073TM259

Equip the inductive transmitters with new O-rings and install them.


- Torque limit : 3.06kgf · m(22.1lbf · ft)

48 Speed-engine

47 Speed-central gear train

21 Speed-turbine

Install breather(Arrow).




73073TM260

Install gasket and cover plate, arrow 1.

- Torque limit : 2.35kgf · m(17.0lbf · ft)

Equip screw plug(Arrow 2) with new O-ring and install it.

- Torque limit : 14.3kgf · m(103.3lbf · ft)




73073TM261

3. AXLE


1) BRAKES

WEAR CHECK AND REPLACEMENT OF BRAKE DISCS

(1) Use till minimum thickness of $s = 4.5\text{mm}$.




(2) Loose fixing nuts and remove horizontally the axle housing.




(3) Remove brake discs.


If the brake discs must not be replaced, remove the complete pack without changing the position of the discs.




(4) For assembling proceed in opposite sense, align lubrication holes.




- (5) Adjustment of brake disc gap. Adjusting bolts counterclockwise and turn them a 3/4 revolution clockwise ; This corresponds to a gap of 0.75mm between the brake discs.




- (6) Remove brake pistons.




- (7) Install O-rings and brake pistons.
Observe that neither the pistons nor the cylinders have scratches or incrostations.




- (8) Tight checking with compressed air at 0.5~1bar for 10 minutes each side.






2) SAFETY BRAKE


- (1) Introduce in the hydraulic circuit 25~35 bar pressure, then remove the axle housing.




- (2) Loose the 4 assembling stud bolts and disassemble the intermediate covers.




- (3) Disassembling of spring applied safety brake pistons. Reassemble the components in opposite sense.




- (4) Check quote of cover.







(5) Remove brake discs.




(6) For assembling align lubrication holes of brake discs.





(7) Remove pinion and ring gear.



(8) Assemble of internal leverism.




(9) Introduce in the hydraulic circuit 25~35 bar pressure and assemble the axen.



ADJUSTMENT



- (1) Introduce pressure in the hydraulic circuit with 25~35 bar.
Remove bolt and locking plate.



- (2) Turn the pinion with 0.82kgf · m(5.9lbf · ft) torque counterclockwise till it stops. Adjust the gap between the brake discs by turning 3 complete revolutions clockwise.




- (3) Adjust the bolts to unlock the safety brake at 47mm and lock the counter nut.




DISASSEMBLY

- (1) Actuate the hydraulic circuit with 5bar.
See following page.




ADJUSTMENT


- (1) See brake disk play adjustment on page 3-141. Near the adjuster screw to the level until the idle stroke has been eliminated (Internal spring action).



- (2) Mount the brake cylinder after pressurizing and adjust the screw so that the two levers rest on the end of travel screws.
Now tighten the lock nut using loctite 242.




- (3) Pressure according to the type of cylinder and spring load curve.






PARKING BRAKE ADJUSTMENT OF CAT 3 AXLES WITH ADJUSTABLE MECHANICAL STOPS.

1. Free both transmission levers from the control wire and from further connections.
2. Apply an 0.8~1.0kgf load to the levers so that the lever rests on the thruster disk without deforming the lever mechanisms.
3. Once in this position, set the adjuster screws of the stops in contact with the levers without deforming the lever mechanisms.
4. Reconnect the control wires to the levers once this position has been obtained.
5. Check that both transmission levers rest against the stop screws during the brake disengagement phase.





**3) WHEEL HUB
DISASSEMBLING AND ASSEMBLING**

(1) Disassembling of wheel hub.




(2) Disassembling the crown wheel
Use partially threaded M18 x 1.5 screws
to support the puller.







Assembling of wheel hub



- a. Installation of outer races of taper roller bearings.
- b. Assembling of bearing.



- c. Fitting of seal.
- d. Fitting of wheel studs.






Assembling of wheel hub, seal and center rings.



4) WHEEL HUB ONTO AXLE HOUSING

(1) Fitting the gear rim on the wheel center.




(2) M18 x 1.5, 10K screws. Mount with loctite 270.

Clamping torque 46.9~47.4kgf · m
(339~343lbf · ft).






(3) Torque of new bearings with seal : From
3.1~4.1kgf · m(22~30lb · ft).




5) WHEEL CENTER VERSION WITH 10 PILOT BOLTS

- (1) Demounting the wheel center version with 10 pilot bolts.






- (2) Clamping torque for bolts M18 x 1.5, 10K
46.9~47.4kgf · m(339~343lbf · ft).



Torque of new bearings with seal : From
3.1~4.1kgf · m(22~30lbf · ft).





6) PLANETARY REDUCTION 6.23
(1) Disassembly




(2) Reassembly



(3) Check the reference numbers.
Torque the screws at $32.1\sim 32.6\text{kgf} \cdot \text{m}$
($232\sim 236\text{lbf} \cdot \text{ft}$).







7) FINAL DRIVE 244-143

DEMOUNTING


(1) Use partially tightened screws as pullers.



(2) Lock the ring nut then remove the hub gear.




(3) Disassembly the hub cover.
Replace the retaining ring.




ASSEMBLY



(1) Assembling the stud bolts.




(2) Dust excluder and oil ring.




(3) Mounting the bearings.




(4) Heat the gear to 140°C for assembly.




- (5) Tighten the ring nut at 81.6~91.8kgf · m
(590~664lb · ft) using loctite 270.




- (6) Chamfer the ring nut.



- (7) Pinion assembly.




- (8) Assembly with loctite 275 on the surfaces.
Take great care to clean the surfaces.



ASSEMBLY AND ADJUSTMENT


- (1) Preassembly with the same shims as those removed during disassembly, or with 1.00mm shims.



- (2) Axle shaft oil seal assembly.


Check the rotation torque applied tangentially to the wheel studs, which must be max 14.3~20.4kgf(With ring).


To correct, add or remove shims considering that a 0.05mm variation cause a variation of ~2.0kgf.



Assembly using loctite 275.


Tighten the screws with a torque wrench 23.4~23.8kgf · m(170~172lbf · ft).






8) REAR AXLE BEVEL PINION SUPPORT


(1) Removal of bevel pinion support.




(2) Flange input.




(3) Flanged to the reduction gear.




(4) Demounting the bearing plus thrust plates.




- (5) Assemble the external races.
Taper roller bearings.
Check cover measurement A.




- (6) Determination of shim pack S1 for the preload of the taper roller bearings $S1 = B - C + X$.
 X = Value to add in order to obtain the correct preload of the taper roller bearings.





 T26/P65 Flange input.




Value X = See figure.




(7) Assembly of bevel pinion support and seal.



(8) Fitting the dust guard on the flange.




(9) Assembly with loctite 242.




FLANGE INPUT VERSION

(1) Tighten the nut with a torque wrench.




(2) Check rotation torque : See figure




9) FRONT AXLE PINION SUPPORT

(1) Demounting the pinions and bearing plates.




(2) How to establish shims S2 to position the bevel pinion. Insert the dummy bearing and check the difference (Photo 3) after having zeroed the instrument on a surface plate with a 20mm shim (Photo 4). Measured difference corresponds to S2. Add or remove the differential shims when the center distances differ from 150mm (Dimension stamped on the pinion).





Example

Center distance : 149.8


Shims = $(150 - 149.8) + S2$




- (3) Establishing the pinion bearing preload shims. See page 3-164 and figure.




- (4) Check the measurement(Photo) after having mounted the shims and thrust plate. It must be 0.10mm~0.15mm less than zero. This difference is annulled by the effect of bearing interference in the definitive assembly.



- (5) Chamfer.



(6) Check the final center distance and stamp it on the cover.



10)276 -176 -143 AXLE ADJUSTMENT OF BEVEL GEAR SET

(1) Determination of shim pack S2 for adjustment of bevel pinion position : $S2 = (l + A) - (D + r)$.




Photo 2 = D, Photo 3 = $\varnothing/2 = r$
 Photo 4 = l (Dimension stamped on the pinion).






Photo 5 = A (Dimension stamped on the cover pinion).




(2) Assembly of bevel pinion support with shim pack S2.





(3) Assembling central axle housing.

Be careful not to damage the tight surfaces of the O-rings while inserting the differential case into the central axle housing.


Play : 0.18~0.25




- (4) Screw in the adjusting nuts to obtain approximate 0.20~0.27mm backlash between the teeth of the bevel gear set, without preloading the taper roller bearings. Check the rotating torque of pinion and differential. Tighten nut on opposite site to the crown wheel to obtain a 0.05~0.07kgf · m(0.37~0.52lbf · ft) higher rotating torque on the pinion.



- (5) Mark both ring nuts. To adjust the backlash move ring nuts only. Loosen the one on bevel crown wheel side and tighten the opposite one for the equal measure if the backlash is too low ; Viceversa if the backlash is too high.





(6) Mount locking tabs in the best position and punch in place.






11) DIFFERENTIAL HOUSING

(1) Removal of the differential from the axle.




Replace the fitting bolts of the crown wheel every time that they have to be removed.






(2) Mounting sun wheels and planet gears.





(3) Insert the spring pins half way up the pin.




(4) Torque all bolts M12 x 35 x 1.25-10K and M12 x 30 x 1.25-10K with a torque wrench bolts clamping torque 13.8~14.1kgf · m(100~102lbf · ft). Use loctite 270.






12)CENTRAL PART OF FRONT AXLE DISASSEMBLY


- (1) Demount the intermediate cover on the opposite side to the gear rim and insert tool.



- (2) Slacken the screws. Insert tool and pull out the differential housing. Remove the gear rim from the pinion bearing side.




T24
P64



ASSEMBLY


- (1) Center the gear rim on tool.



- (2) Insert the differential housing with tool and torque the screws.



- (3) Take care to prevent damage to the brake retention zones when assembling the parts.



- (4) Mount the intermediate cover on the gear rim side using tools. Fit on the other intermediate cover.

