

GROUP 2 ELECTRICAL CIRCUIT (1/2)

FRAME HARNESS

NO.	DESTINATION
1	AC CONTROLLER GND
2	REAR WIPER MOTOR SW
3	AC 24V
4	NC
5	AC CONTROL
6	AC CONTROL
7	AC CONDENSER FAN
8	ILLUMINATION
9	NC
10	BEACON LAMP
11	CABIN LIGHT
12	NC

NO.	DESTINATION
1	CASSETTE RADIO 24V
2	ILLUMINATION
3	NC
4	NC
5	CASSETTE ROOM LAMP B
6	NC
7	CASSETTE GND
8	NC
9	BEACON LAMP
10	CABIN LIGHT
11	NC
12	NC

NO.	DESTINATION
1	HORN SW
2	HORN SW
3	NC
4	INT. SIG.
5	ACCEL. SW(L)
6	ACCEL. SW(R)
7	ACCEL. SW(L)
8	SPARE SW

NO.	DESTINATION
1	SPARE SW
2	SPARE SW
3	BEACON LAMP 24V
4	BEACON LAMP SW
5	BREAKER SW 24V
6	BREAKER SW
7	SPARE SW
8	SPARE SW
9	START KEY (START SIG)
10	START KEY (ACC)
11	START KEY (SIG)
12	START KEY (COM)

NO.	DESTINATION
1	ILLUMINATION
2	HEAD LIGHT SIG
3	WIPER DRIVE SW
4	PRE HEAT
5	SW PANEL SW
6	CABIN LIGHT 24V
7	ILLUMINATION 24V
8	HEAD LIGHT 24V
9	WASHER SIG
10	GND
11	WORK LAMP SW
12	CABIN LIGHT 24V
13	SEAT HEATER
14	NC
15	NC

NO.	DESTINATION
1	TOCK COOLING SW
2	TOCK COOLING SW SW
3	COVER SW
4	COVER SW
5	WIPER MOTOR 24V
6	GND
7	CLEARLIGHTER SW
8	CLEARLIGHTER SW
9	WIPER DRIVE SW
10	WIPER SW
11	WASHER PUMP
12	TRAVEL MODE

NO.	DESTINATION
1	WASHER SIG
2	WIPER MOTOR
3	WIPER MOTOR 24V
4	WIPER MOTOR CONT
5	COVER SW
6	COVER SW
7	WIPER MOTOR SW
8	WIPER MOTOR SW
9	SHIELD
10	CLUSTER SERIAL (RX)
11	CLUSTER SERIAL (TX)
12	WIP SELECT SW
13	FLASHER(L)
14	GND
15	FLASHER(R)

NO.	DESTINATION
1	MULTI SW
2	HAZARD SW
3	MULTI SW(L)
4	MULTI SW(R)
5	MULTI SW(L)
6	MULTI SW(R)
7	MULTI SW(L)
8	MULTI SW(R)
9	MULTI SW(L)
10	MULTI SW(R)
11	MULTI SW(L)
12	MULTI SW(R)

NO.	DESTINATION
1	PARKING SW
2	LAMP 24V
3	HAZARD SW
4	DO SW
5	DO SW
6	DO SW
7	DO SW
8	NC
9	GND
10	NC

NO.	DESTINATION
1	MULTI SW
2	HAZARD SW
3	MULTI SW(L)
4	MULTI SW(R)
5	MULTI SW(L)
6	MULTI SW(R)
7	MULTI SW(L)
8	MULTI SW(R)

NO.	DESTINATION
1	POWER MAX SW
2	POWER MAX SW
3	OFF DECEL SW
4	OFF DECEL SW
5	NC
6	SAFETY SW (COM)
7	SAFETY SW (NC)
8	SAFETY SW (NO)

NO.	DESTINATION
1	MULTI SW
2	HAZARD SW
3	MULTI SW(L)
4	MULTI SW(R)
5	MULTI SW(L)
6	MULTI SW(R)
7	MULTI SW(L)
8	MULTI SW(R)

NO.	DESTINATION
1	REAR COMBI-RH
2	FRONT COMBI-RH
3	REAR COMBI-LH
4	FRONT COMBI-LH

NO.	DESTINATION
1	TRAVEL BZ
2	REV. RY
3	FWD. RY

NO.	DESTINATION
1	RAMLOCK SOL

NO.	DESTINATION
1	DOOR/OUTRIGGER SELECTOR SOL

NO.	DESTINATION
1	REAR COMBI-RH
2	FRONT COMBI-RH
3	REAR COMBI-LH
4	FRONT COMBI-LH

NO.	DESTINATION
1	TRAVEL BZ
2	REV. RY
3	FWD. RY

NO.	DESTINATION
1	RAMLOCK SOL


NO.	DESTINATION
1	DOOR/OUTRIGGER SELECTOR SOL

NO.	DESTINATION
1	REAR COMBI-RH
2	FRONT COMBI-RH
3	REAR COMBI-LH
4	FRONT COMBI-LH

NO.	DESTINATION
1	TRAVEL BZ
2	REV. RY
3	FWD. RY

NO.	DESTINATION
1	RAMLOCK SOL

NO.	DESTINATION
1	DOOR/OUTRIGGER SELECTOR SOL








## 1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis through master switch.

When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

### 1) OPERATING FLOW




### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
OFF	OFF	① - GND (Battery 1EA)	10~12.5V
		② - GND (Battery 2EA)	20~25V
		③ - GND (Battery 2EA)	20~25V
		④ - GND (Fusible link)	20~25V

※ GND : Ground

# POWER CIRCUIT



14W7A4EL03

## 2. STARTING CIRCUIT

### 1) OPERATING FLOW

Battery(+) terminal → Battery relay〔CR-1〕 → Fusible link〔CN-60〕 → Master switch〔CS-74〕  
 → Fuse box〔No.1〕 → I/conn〔CN-8(12)〕 → Start switch〔CS-2(1)〕

#### (1) When start key switch is in ON position

→ Start switch ON〔CS-2(2)〕 → I/conn〔CN-8(11)〕 → Battery relay〔CR-1〕  
 → Battery relay operating (All power is supplied with the electric component)  
 → Start switch ON〔CS-2(3)〕 → I/conn〔CN-8(10)〕 → Power relay〔CR-35(86) → (87)〕  
 → Fuse box〔No.10〕

#### (2) When start key switch is in START position


Start switch START〔CS-2(5)〕 → I/conn〔CN-8(9)〕 → Anti-restart relay〔CR-5(86) → (87)〕  
 → I/conn〔CN-2(2)〕 → Start relay〔CR-23〕

### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
OPERATING	START	① - GND(Battery) ② - GND(Start key) ③ - GND(Battery relay M4) ④ - GND(Starter B+) ⑤ - GND(Starter M) ⑥ - GND(Start relay) ⑦ - GND(Battery relay M8)	20~25V

※ GND : Ground

# STARTING CIRCUIT



14W74AEL04

### 3. CHARGING CIRCUIT

When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery through the battery relay (CR-1).

The current also flows from alternator to each electrical component and controller through the fuse box.

#### 1) OPERATING FLOW

##### (1) Warning flow

Alternator "I" terminal → I/conn [CN-2(3)] → CPU alternator level [CN-51(9)]

Cluster charging warning lamp(Via serial interface)

##### (2) Charging flow


Alternator "B+" terminal → Battery relay(M8) → Battery(+) terminal  
 → Fusible link [CN-60] → Master switch[CS-74]  
 → Fuse box

#### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
Run	ON	① - GND(Battery voltage) ② - GND(Battery relay) ③ - GND(Alternator B+ terminal) ④ - GND(Alternator I terminal) ⑤ - GND(CPU)	20~30V

※ GND : Ground

# CHARGING CIRCUIT



## 4. HEAD AND WORK LIGHT CIRCUIT

### 1) OPERATING FLOW

Fuse box (No.15) → I/conn [CN-7(8)] → Switch panel [CN-116(10,11)]

Fuse box (No.16) → I/conn [CN-7(7)] → Switch panel [CN-116(9)]

#### (1) Main light switch ON : 1st step

Head light switch ON [CN-116(2,3)] → I/conn [CN-7(2)] → I/conn [CN-97(11)] →

Multifunction sw left lever(4) → (5) → [CN-97(10)] → Head light relay [CR-13(86)→(87)] →

Head light ON [CL-3(1), CL-4(1)] : Head lamp ON

#### (2) Main light switch ON : 2nd step

Work light switch ON [CN-116(14)] → I/conn [CN-7(11)] → Work light relay [CR-3(86)→(87)]


→ I/conn [CN-12(1)] → Work light ON [CL-5(2), CL-6(2)]

### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
STOP	ON	① - GND(Fuse box) ② - GND(Switch power input) ③ - GND(Switch power output) ④ - GND(Head light relay)	20~25V
STOP	ON	⑤ - GND (Head light) ⑥ - GND(Fuse box) ⑦ - GND(Switch power input) ⑧ - GND(Switch power output) ⑨ - GND(Work light)	20~25V

※ GND : Ground

# HEAD AND WORK LIGHT CIRCUIT



## 5. BEACON LAMP AND CAB LIGHT CIRCUIT

### 1) OPERATING FLOW

Fuse box (No.18) → I/conn [CN-8(3)] → Beacon lamp switch [CS-23(6)]

Fuse box (No.17) → I/conn [CN-7(12)] → Switch panel [CN-116(16, 17)]

#### (1) Beacon lamp switch ON

Beacon lamp switch ON [CS-23(2)] → Switch Indicator lamp ON [CS-23(9)]  
 → I/conn [CN-8(4)] → I/conn [CN-10(10)]  
 → Beacon lamp ON [CL-7]

#### (2) Cab light switch ON


Cab light switch ON [CN-116(7, 8)] → I/conn [CN-7(6)] → I/conn [CN-10(11)]  
 → Cab light ON [CL-8(2), CL-9(2)]

### 2) CHECK POINT

Engine	Start switch	Check point	Voltage
STOP	ON	① - GND(Fuse box) ② - GND(Switch power input) ③ - GND(Switch power output) ④ - GND(Beacon lamp)	20~25V
STOP	ON	⑤ - GND(Fuse box) ⑥ - GND(Switch power input) ⑦ - GND(Switch power output) ⑧ - GND(Cab light)	20~25V

※ GND : Ground


# BEACON LAMP AND CAB LIGHT CIRCUIT




14W7A4EL07




# WIPER AND WASHER CIRCUIT



# ILLUMINATION CIRCUIT




# COMBINATION LAMP CIRCUIT




14W7A4EL10

# CONTROLLER CIRCUIT



# MONITORING CIRCUIT



14W7A4EL12

# ELECTRIC CIRCUIT FOR HYDRAULIC

