


1. POWER CIRCUIT

The negative terminal of battery is grounded to the machine chassis through master switch.
When the start switch is in the OFF position, the current flows from the positive battery terminal as shown below.

1) OPERATING FLOW

Battery → Battery relay → Fusible link (CN-60) → I/conn [CN-3 (2)] → Master switch [CS-74]




※ I/conn : Intermediate connector

2) CHECK POINT

Engine	Start switch	Check point	Voltage
OFF	OFF	① - GND (battery) ② - GND (relay) ③ - GND (fusible link)	10~12.5V

※ GND : Ground

POWER CIRCUIT



2. STARTING CIRCUIT

1) OPERATING FLOW

Battery (+) terminal → Battery relay[CR-1] → Fusible link [CN-60]
 → I/conn [CN-3 (2)] → Master switch [CS-74] → Fuse box No.1 → Start key [CS-2 (1)]

※ Start switch : ON

→ Start switch ON [CS-2 (2)] → I/conn [CN-5 (15)] →
 Battery relay [CR-1] : Battery relay operating (all power is supplied with the electric component)
 → Start switch ON [CS-2 (3)] → Fuse box (all power is supplied with electric component)

※ Start switch : START

Start switch START [CS-2 (5)] → Anti-restart relay [CR-5 (86)→(87)] → I/conn [CN-2 (5)]
 → Start relay [CR-23 (2)→(2)] → Start motor operating

2) CHECK POINT

Engine	Start switch	Check point	Voltage
Operating	Start	① - GND (battery) ② - GND (battery) ③ - GND (fusible link) ④ - GND (starter B ⁺) ⑤ - GND (starter M) ⑥ - GND (start relay) ⑦ - GND (battery relay M8)	10~12.5V

※ GND : Ground

3. CHARGING CIRCUIT

When the starter is activated and the engine is started, the operator releases the key switch to the ON position.

Charging current generated by operating alternator flows into the battery through the Battery relay (CR-1).

The current also flows from alternator to each electrical component and controller through the fuse box.

1) OPERATING FLOW

(1) Warning flow

Alternator "L" terminal → I/conn [CN-1 (2)] → Cluster [CN-56 (3)] → Cluster warning lamp
 Alternator "L" terminal → DC motor controller [CN-51 (1)]

(2) Charging flow


Alternator "B+" terminal → Battery relay → Battery (+) terminal

2) CHECK POINT

Engine	Start switch	Check point	Voltage
ON	ON	① - GND (battery voltage) ② - GND (battery relay) ③ - GND (alternator B+ terminal) ④ - GND (alternator L terminal) ⑤ - GND (cluster)	10~12.5V


※ GND : Ground

CHARGING CIRCUIT



55W94EL07

HEAD AND WORK LAMP CIRCUIT



5. BEACON LAMP AND CAB LAMP CIRCUIT

1) OPERATING FLOW

Fuse box (No.13) → Beacon lamp relay [CR-85 (30)→(85)] → Switch panel [CN-116 (6)]

Fuse box (No.11) → Cab lamp relay [CR-9 (30)→(85)] → Switch panel [CN-116 (7)]

(1) Beacon lamp switch ON

Switch panel [CN-116 (6)] → Beacon lamp relay [CR-85 (85)→(87)] → I/conn [CN-6 (1)]

→ Beacon lamp [CL-7]

(2) Cab lamp switch ON

Switch panel [CN-116 (7)] → Cab lamp relay [CR-9 (85)→(87)] → I/conn [CN-6 (4)]


→ Cab lamp [CL-9 (2)]

2) CHECK POINT

Engine	Start switch	Check point	Voltage
STOP	ON	① - GND (fuse box) ② - GND (switch power input) ③ - GND (switch power output) ④ - GND (beacon & cab lamp)	10~12.5V

※ GND : Ground

BEACON LAMP AND CAB LAMP CIRCUIT




55W94EL09


6. WIPER AND WASHER CIRCUIT

1) OPERATING FLOW


(1) Key switch ON




(2) Wipe switch ON : 1st step (intermittent)




(3) Wiper switch ON : 2nd or 3rd step



(4) Auto parking (when switch OFF)



(5) Washer switch ON




2) CHECK POINT

Engine	Start switch	Check point	Voltage
STOP	ON	① - GND (fuse box) ② - GND (wiper motor)	10~12.5V


※ GND : Ground

WIPER AND WASHER CIRCUIT




55W94EL10

ILLUMINATION CIRCUIT




55W94EL12

COMBINATION LAMP CIRCUIT



55W94EL13

ELECTRIC CIRCUIT FOR HYDRAULIC



55W94EL14