

## 4. PARKING

When leaving the machine lower the bucket to the ground completely and put the safety lever at parking position then remove the key.

Lock the cab door.

Park the machine in the flat and safe place.

Hope you can work easily and safely observing safety rules.

For safe operation, observe all safety rules.