

CONTENTS

EC declaration of conformity	0-1	9. Operation in the special work sites	4-23
Foreword	0-2	10. Storage	4-25
Before servicing this machine	0-3		
Table to enter S/No and distribution	0-4		
EC regulation approved	0-5		
Safety labels	0-6		
Machine data plate	0-14		
Guide (direction, S/No, symbol)	0-15		
		5. TRANSPORTATION	
1. SAFETY HINTS		1. Road traveling	5-1
1. Before operating the machine	1-1	2. Preparation for transportation	5-2
2. During operating the machine	1-5	3. Loading the machine	5-3
3. During maintenance	1-14	4. Fixing the machine	5-4
4. Parking	1-18	5. Loading and unloading by crane	5-6
		6. Towing the machine	5-7
2. SPECIFICATIONS			
1. Major components	2-1	6. MAINTENANCE	
2. Specifications	2-2	1. Instructions	6-1
3. Weight	2-6	2. Tightening torque	6-5
4. Specification for major components	2-7	3. Spec of fuel, coolant and lubricants	6-8
		4. Maintenance check list	6-10
3. CONTROL DEVICES		5. Maintenance chart	6-13
1. Cab devices	3-1	6. Service instruction	6-15
2. Cluster	3-2	7. Electrical system	6-41
3. Monitors	3-11	8. Air conditioner and heater	6-44
4. Switches	3-25		
5. Control device	3-33	7. TROUBLESHOOTING GUIDE	
6. Air conditioner and heater	3-37	1. Engine	7-1
7. Others	3-41	2. Electrical system	7-2
		3. Power train system	7-3
4. OPERATION		4. Hydraulic system	7-4
1. Suggestion for new machine	4-1		
2. Check before starting the engine	4-2	8. INDEX	8-1
3. Starting and stop the engine	4-3		
4. Warming-up operation	4-8		
5. Operation of the working device	4-9		
6. Traveling of the machine	4-10		
7. Efficient working method	4-15		
8. Adjustment of the work equipment	4-22		