

3. OTHERS

| Trouble | Service | Remark |
|--|--|--------|
| Bucket either rises slowly or not at all. | <ul style="list-style-type: none">• Add oil to specified level. | |
| Slow speed of travel, swing, boom, arm and bucket. | <ul style="list-style-type: none">• Add oil to specified level. | |
| Unusual noise emitted from pump. | <ul style="list-style-type: none">• Clean the hydraulic tank strainer. | |
| Excessive oil temperature rise of hydraulic oil. | <ul style="list-style-type: none">• Clean the oil cooler.• Adjust fan belt tension.• Add oil to specified level. | |