

### 3. OTHERS

| Trouble   | Service  | Remark |
|---|--|--------|
| Track slip out of place.<br>Excessive wear of the sprocket. | <ul style="list-style-type: none"><li>• Adjust tension of track.</li></ul>   |        |
| Bucket either rises slowly or not at all.                   | <ul style="list-style-type: none"><li>• Add oil to specified level.</li></ul>  |        |
| Slow speed of travel, swing, boom, arm and bucket.          | <ul style="list-style-type: none"><li>• Add oil to specified level.</li></ul>  |        |
| Unusual noise emitted from pump.                            | <ul style="list-style-type: none"><li>• Clean the hydraulic tank strainer.</li></ul>   |        |
| Excessive oil temperature rise of hydraulic oil.            | <ul style="list-style-type: none"><li>• Clean the oil cooler.</li><li>• Adjust fan belt tension.</li><li>• Add oil to specified level.</li></ul> |        |