

3. OTHERS

Trouble	Service	Remark
Track slip out of place. Excessive wear of the sprocket.	Adjust tension of track.	
Bucket either rises slowly or not at all.	Add oil to specified level.	
Slow speed of travel, swing, boom, arm and bucket.	Add oil to specified level.	
Unusual noise emitted from pump.	Clean the hydraulic tank strainer.	
Excessive oil temperature rise of hydraulic oil.	- Clean the oil cooler. - Adjust fan belt tension. - Add oil to specified level.	