



## GROUP 4 SWITCHES




### 1) MASTER SWITCH



- (1) This switch is used to shut off the entire electrical system.
- (2) **I** : The battery remains connected to the electrical system.  
**O** : The battery is disconnected to the electrical system.
- ※ **Never turn the master switch to O(OFF) with the engine running. Engine and electrical system damage could result.**

### 2) HORN SWITCH



- (1) Push the knob down to sound the horn. Use the horn to alert or to signal personnel.