


## GROUP 5 TRAVEL SPEED CONTROL SYSTEM



### 1. TRAVEL SPEED SELECTION

Travel speed can be switched manually by turning the travel speed switch on the LH multifunction switch.

Speed	Travel speed solenoid valve	Lamp on cluster	Operation
Lo	OFF	Turtle	Low speed, high driving torque in the transmission
Hi	ON	Rabbit	High speed, low driving torque in the transmission

※ Default : Turtle(Lo)

### 2. POWER BOOST IN TRAVEL

When operator's travel in condition of the power mode H or S, if the power boost switch is pressed CPU controller sends control signal to set pressure of the main relief valve from 320 to 350kgf/cm<sup>2</sup> to increase travel power.